

Work Order ID 73121

Thursday, August 25, 2011 4:13:48 PM



Page 1

Item ID: D206-642-512

Accept



Setup Start



Revision ID:

Stop



Item Name: Float Skidtube RH

Start Date: 8/26/2011 Start Qty: 1.00



Cust Item ID:

Required Date: 9/9/2011 Req'd Qty: 1.00



Customer:

Reference:

Run Start

Approvals: Process Plan: CL Date: 11/08/26

Tooling:

Date:

QC: _____ Date: _____

SPC (Y/N): _____

Date:

Stop



Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr	Revision Nbr
INN-D206-642	Rev M

100

0.00



DOCUMENT CONTROL

DC

Memo

0.00

Document Control

Photocopy bluefile and create labels per PPP D206-642-512 CHG004

Sulorizo

Jfor MF 11-9-21

110

0.00



Pick Kit

Packaging

Memo

0.00

Packaging

R 11/9/30

120

0.00



QC4- 100% Inspect kits for completeness

QC

Memo

0.00

Quality Control

Sulorizo

①

W/O:		WORK ORDER CHANGES						
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector	

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Work Order ID 73121

Thursday, August 25, 2011 4:13:48 PM



Page 2

Item ID: D206-642-512

Accept



Setup Start



Revision ID:

Stop



Item Name: Float Skidtube RH

Start Date: 8/26/2011 Start Qty: 1.00



Cust Item ID:

Required Date: 9/9/2011 Req'd Qty: 1.00



Customer:

Reference:

Run Start



Approvals: Process Plan: _____ Date: _____ Tooling: _____ Date: _____

Stop



QC: _____ Date: _____ SPC (Y/N): _____ Date: _____

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
130		0.00							
	Packaging								
Packaging	Memo	0.00							
Packaging	Identify and pack for shipping as per PPP D206-642-512 Location: _____								
140		0.00							
	QC21- Final Inspection - Work Order Release								
QC	Memo	0.00							
Quality Control									

Rec'd 8/30/11

11/9/30

MF 11-09-30

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Picklist Print

Thursday, August 25, 2011 4:13:45 PM

Page 1

Work Order ID: 73121

Parent Item: D206-642-512

Parent Item Name: Float Skidtube RH



Start Date: 8/26/2011

Required Date: 9/9/2011

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP Rev:B 05.09.23 Revised per D206-642 Rev. J KJ/JLM
 IPP Rev:C 07-02-23 As per IIN D206-642 Rev K JLM
 IPP rev D 07.06.06 added K642-512 EC
 IPP Rev:E 07-12-05 ECN 1080p Rev L DD verified by:

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
---------------------------------	------------------------	---------------	-------------	---------------------	------------------	-----------------	--------------------	----------------	-------------	--------------	---------------	----------------	--------

D206-642-541

Manufactured

No

120

Each

1.0000

1

1



Replacement Skidtube



72957 *[Signature]*

Location

Loc Qty

Loc Code

FG073

1

34772

1

K642-512

Manufactured

No

120

Each

2.0000

1



saddle kit 642-512



73 420 *[Signature]*

Location

Loc Qty

Loc Code

PKG

2

69940

2

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries